Product Functions

- 01. Purify the tap water in a simple way.
- 02. Enjoy 3.5L of sufficient amount of water.
- 03. Easy to check the service life of filter by indicator filter.
- 04. Enjoy more clean water by applying the selective filter.
- 05. Improve the taste of foods by using the water as cooking purpose,



1. Fill the white tank in the top of the water pitcher with the tap water.

into the ideal water for drinking or cooking.

2. Filled tap water will pass through the optimised premium filter.



Safe and Clean Water! Water Pitcher is always with you.

WATER PITCHER

ADVANTAGE . 1

Easy to handle for filter replacement

Indicator for the longevity of the filter. Easy to check the service life of filter.

ADVANTAGE . 2

Sensational Design

User-friendly design to put it in the fridge with Unique Design and Compact Size.



ADVANTAGE . 3

Economical Price

Able to enjoy the drinking water safely at a reasonable price of water pitcher







The Excellent Company **Brand of Seoul**



INSTALLATION & MAINTENANCE GUIDE

Water Filtration System

Safe & Clean water by New filter of Water Pitcher



Filter Technology 96% Chlorine Taste and Odor Reduction. Enjoy the safe drinking water by this Water Pitcher at Economic price.





Do not use where water is micro biologically unsafe or with water that has not been disinfected in the prescribed and knowing manner. The water quality can differ from area to area in some instances one might require additional water purifying devices.

Instruction For Use



 Open the filter packing, wash the with tap water.

USER'S GUIDE



Dip the filter into water for about 20 minutes.



Wash the jug and filter holder throughly before use it.

Drain the first two glasses of water.




 Insert the filter to the filter holder and gently press in.



Pour the required amount of cold tap water into the filling funnel.

Naturife





How to use "Mechanical Indicator



 There are three kinds which are one person, two person and three person. You can choose the kind by your situation.



For example, one person use the water purifier pitcher which is starting from January 1st. Turn the mechanical indicator and make the one person's arrow point to JAN 1 in the back of the cover.



The front of the cover will show you the replace time of the filter.

Attention:

- If the date is not in the mechanical indicator in the back of the cover, please choose the lastest date as starting date.
- Do not dial the mechanical indicator before replace the filter.





MADE IN KOREA

Useful Tips & Precautions

 Water pitcher is only used for cold water. (Water source : Tap water)

DO NOT FILL HOT WATER IN THE JUG. (MAX 85 °F / 30 °C)

- After draining out water from the pitcher, add more water right away to keep the filter cartridge wet. If the filter cartridge dries out, it may need to soak before being used. If the filter cartridge becomes too dried out, it is necessary to be replaced.
- Allow water to filter completely before pouring or refilling reservoir.
- Keep the filtered water refrigerated at all times. If no use of filtered water for three or four days, replace the unused water with fresh water.
- All parts except the filter cartridge should be washed regularly. It is important to keep food and beverage equipment clean and sanitary.
- DO NOT USE DISHWASHER TO CLEAN PITCHER, RESERVOIR AND LID.

